




MyToyota App – Remote Climate – Guide




REMOTE CLIMATE PART 1 – FULL CLIMATE CONTROL



STEP 1

On the home screen, tap on "Start Climate" to open the remote climate settings page.




STEP 2

You can adjust the temperature of the air conditioning and start it immediately or at a pre-set time.




REMOTE CLIMATE PART 1 – FULL CLIMATE CONTROL



STEP 3

All the climate control features* are shown in the toggle list.

* Availability of the features may vary depending on your model and grade. Please contact your dealer for more information.




STEP 4

Select the settings and tap "Start Climate".




REMOTE CLIMATE PART 1 – FULL CLIMATE CONTROL



Full climate control will run for 10 minutes*.

* Depending on the car model the climate will run for 2x10 or 1x20 minutes.



STEP 5

To stop climate control before the timer ends, tap on the "Stop Climate" icon.



REMOTE CLIMATE PART 1 – FULL CLIMATE CONTROL




STEP 6

Then tap on "Stop Climate".




REMOTE CLIMATE PART 2 – SCHEDULE REMOTE CLIMATE CONTROL



STEP 1

You can schedule your climate control to activate at a specific time.

On the home screen, tap on "Climate Schedule" to open the next screen.




STEP 2

Tap "Add a New Schedule".




REMOTE CLIMATE PART 2 – SCHEDULE REMOTE CLIMATE CONTROL



STEP 3

Select the desired start time, temperature and settings.




STEP 4

You can also choose to repeat the schedule later in the week.



REMOTE CLIMATE PART 2 – SCHEDULE REMOTE CLIMATE CONTROL



STEP 5

Tap "Save Schedule".




STEP 6

The "Climate Schedule" page shows all schedules.



REMOTE CLIMATE PART 2 – EDIT & DELETE A CLIMATE CONTROL SCHEDULE



STEP 1

On the home screen, tap on "Climate Schedule" to open the next screen.



STEP 2

Select the schedule to edit.




REMOTE CLIMATE PART 2 – EDIT & DELETE A CLIMATE CONTROL SCHEDULE



STEP 3

Make the desired changes and tap on "Save Schedule".




STEP 4

To delete a schedule, tap "Delete schedule".



REMOTE CLIMATE PART 2 – EDIT & DELETE A CLIMATE CONTROL SCHEDULE



STEP 5

The "Climate Schedule" page shows Remaining schedules, if any.



EVERY FEATURE COUNTS

Connected Services are continually improving, therefore visuals and app screens in this guide may slightly differ from those seen in your MyToyota App.

